

44(0)1473

www.sfservices.com Email: info@sfservices.com

Heidelberg 10" x 15" / 26cm x 38cm **T Platen Foil Blocking Conversion**

Maitland Road, Needham Market, Ipswich, Suffolk, UK





The **Foil Expert** is simply the most innovative and simple hot foil conversions to use and fit, integrating neatly into the original press design; installation requires no drilling or screw fixings. We have designed the kit for guick and easy installation, without compromising style and quality

Our Ref:

2009d

Key Features: 1-Year part warranty 1 new foil pull unit – (hologram registration optional extra) 1 zone low profile honeycomb heater plate (lightweight 6 kg) Foil tension mounting system (up to 6 foil rolls)

> Price: **On Request**





Heidelberg 10" x 15" Platen Foil Blocking Conversion – FOIL EXPERT

www.sfservices.com Email: info@sfservices.com

SF Services Unit 29 Maitland Road, Needham Market, Ipswich, Suffolk, UK

Foil Expert

Features:

- Quick and easy to install (self-installation)
- Substantially constructed and mounted on the top of the press
- Up to two full width rewind rollers (optional extra)
- Each foil unit features a microprocessor control
- Complex foil advance program to cope with demanding foil layouts

Tel:+44(0)1473 725161 Fax: +

- Hologram registration available (optional extra)
- "Step-ins" even when running registered holograms



- 1. Using Fixed lays only will allow the use of the 1" Foil bar
- 2. Using fixed lays and register lays see appendix 1

Features:

- Comprises of spring loaded bar
- Incorporates up to 6 foil rolls
- Foil diameter 60mm (122m rolls) * See appendix 1
- Controls foil tension from a full roll to the empty core
- Two guide bars supplied to ensure the foil does not touch the die
- Foil bar 1" or 25.4mm core size * See appendix 1
- Number of pulls per length up to 99

Heated bed

Features:

- Low profile toggle honeycomb heater plate
- Single zone temperature controlled
- Heat sensor is close to the surface of the bed so it accurately measure the temperature of the die
- Set for 6.35mm dies (can be modified for 7.0mm)
- Light weight 6.5kg

Electrical system

Features:

- Single phase 16 Amp, 3 pin plug
- Stepper motor foil pull control pull resolution- 0.1mm
- Acceleration and deceleration for the stepper motor
- Inch foil advance
- Push button keypad (LCD)
- 110v / 220 240v
- Temperature control system











Heidelberg 10" x 15" Platen Foil Blocking Conversion – FOIL EXPERT

Tel:+44(0)1473 725161 Fax: +44(0)1473 271601 www.sfservices.com Email: info@sfservices.com

SF Services Unit 29 Maitland Road, Needham Market, Ipswich, Suffolk, UK

Maintenance history and documentation

The machine includes:

- Machine documentation
 - Operators manual
 - Parts Manual
 - Electrical wiring diagram

Installation, commissioning and requirements

The conversion dimensions are: Height 290mm x width 900mm x depth 300mm - Weight 10kg The electrical supply is: single phase 110 or 220/240v - 50Hz

SF Services can install and commission the conversion anywhere in the world using our own skilled engineers. Please ask for a price.

Warranty

This machine is offered with 1-Year parts warranty, subject to our terms and conditions, which are available on request.

Disclaimer

These details have been prepared in good faith but do not form part of any contract. It is for the purchaser to inspect the machine and satisfy themselves as to the suitability and condition of the machine prior to entering into any contract.













Heidelberg 10" x 15" Platen Foil Blocking Conversion – FOIL EXPERT

SF Services Unit 29 Maitland Road, Needham Market, Ipswich, Suffolk, UK

Foil Handling Maximum foil diameter Foil core size Minimum distance between foil rolls Number of foil rewinds Number of Lengths per program Number of pulls per length Pull Resolution Hologram	122 meters 25.4mm (12mm / 16mm core optional) 2mm 1 full width (2 optional) 5 Up to 99 0.1mm (Optional)
Heating Heat Zones Temperature range Temperature sensors Die Height Bed Plate Die fixing method	1 0-200 degrees centigrade Single zone control (1) 6.35mm / ¼" (7mm available on request) Honeycomb Toggle Bed – Lightweight 6kg Low Profile Toggle
General Dimensions approximate Weight (kg) Air Supply Machine power supply Duty Cycle	2,080mm (L) x 1,480mm (W) 2,235kg (approx.) Not required Single phase neutral and earth connections 240 VAC 50 / 60 Hz, 3 kW Continuously rated





Appendix 1

T presses have 2 register methods, 1. Fixed lays 2. Register lay bar mechanism.

SF Services Unit 29 Maitland Road, Needham Market, Ipswich, Suffolk, UK

Using Lay bar mechanism and fixed lays, you can only use a 12mm / 16mm foil bar with a reduced width of the heater plate, this is due to the presses lay bar mechanical linkage, shown below.

1. Using both sheet register methods 12mm foil tension bar and collars. Lay Linkage still fitted



2. Using only fixed lay register Full use of heater plate and Lay bar linkage removed.



BPiF picon









Heidelberg T 10x15 Basic installation instructions.

SF Services Unit 29 Maitland Road, Needham Market, Ipswich, Suffolk, UK

Tel:+44(0)1473 725161 Fax: +44(0)1473 271601 www.sfservices.com Email: info@sfservices.com

9 simple steps to install a Foil Expert

- 1. Install Foil Expert mounting frame
- 2. Place Foil Expert on mounting bracket secure both sides
- 3. Square / level Foil Expert using rear adjusting screws.
- 4. Tighten Foil Expert side bolts.
- 5. Place heater plate in position using original points
- 6. Secure heater plate side strips using original bolt holes
- 7. Plug heater plate supply lead plug into Foil Expert socket
- 8. Plug in foil expert to standard 240/220 or 110 volt socket
- 9. Switch on Unit Very simple to install
- 10. Certain top guards will require slightly modifying to secure back on top.
- 11. Fit Pull-through sensor to provide a signal to Foil Expert each machine revolution.
- 12. Full instructions will accompany the Foil Expert.
 - a. Installation manual
 - b. Electrical wiring manual
 - c. Operations manual
 - 1. Foil Expert mounting points (2 x Heidelberg Original fixing points)



FOIL EXPERT Level adjusting screws





Left side mounting frame securing point

Right side mounting frame securing point

SF Services Unit 29 Maitland Road, Needham Market, Ipswich, Suffolk, UK



Foil Expert Left side mounting bracket securing point



Foil Expert Right side mounting bracket securing point

HEATER PLATE MOUNTING USES ALL ORIGINAL LOCATION POINTS



Heater plate right bottom securing point







HEATER PLATE MOUNTING USES ALL ORIGINAL LOCATION POINTS

SF Services Unit 29 Maitland Road, Needham Market, Ipswich, Suffolk, UK

Tel:+44(0)1473 725161 Fax: +44(0)1473 271601 www.sfservices.com Email: info@sfservices.com

<section-header>

Fit Sensor at pump location using original Heidelberg drillings.

*Bracket with sensor fitted is secured in position using the pump drive housing.

*When the pump rotates part 1. Passes the sensor Part 2 and activates the Foil Expert each time. PUMP ARM



BPif picon



SF Services Unit 29 Maitland Road, Needham Market, Ipswich, Suffolk, UK **SF SERVICES** Tel:+44(0)1473 725161 Fax: +44(0)1473 271601 www.sfservices.com Email: info@sfservices.com

Other features:

Heater plate plug & socket to allow removal of Heater plate to =

Set up dies or insert Cutting Chase for cutting & Creasing



Heater plate side locating plates (Using original Heidelberg fixing holes)

